

Colonial / Board & Batten Shutters

- Lay both panels on flat surface, side by side with the back side facing up
- Attach locking bar to panels with sidewalk bolts
- Align shutter to wall; attach hinges to mark holes for pre-drilling
- Take down shutter & drill holes into wall
- Align shutters back on wall; attach hinges to shutter & screw to wall
- Remove lock bar & open the shutter
- Screw bullet clip to the backside of each panel for the hold back; mark & predrill hole for panel mate
- Screw panel mate to wall and screw on bullet
- Close shutter on to bullet clip to hold back in the open position

