

PSI Dura-Prene Brand Shutter Painting Instructions

For Paintable, Styrene Products Only –

(not for products that were bought in a specific “color” or “color through”)

1. Do not expose shutter to direct sunlight before, during or immediately after painting. Temperature should be between 60 and 90 degrees Fahrenheit for best results.
2. Clean shutter panels using a mixture of ammonia and water (1 cup per gallon) or soap and water, follow direction on container. Rinse thoroughly and allow to dry 1 hour.
3. Prime shutters with a good primer. The manufacturer recommends Sherwin Williams Adhesion Primer, B51 W 8050 White, 6501-32590. Follow manufacturer’s recommendations.
4. **For best results use high quality oil base or latex paint for top coat. DO NOT USE ANY TYPE OF VINYL BASED PAINT.**
5. Apply two coats of finish paint following the manufacturer’s recommendations on the amount of time between coats. The paint can be applied with a brush or spraying following the paint manufacturer’s recommendations.
6. Allow the shutters to dry four days prior to installation, especially if the shutter will be exposed to direct sunlight and high temperatures. This will allow the paint to fully cure.